

# PRODUCT DESCRIPTION

Kansai Nerolac Goody Synthetic Enamel is an economical general purpose synthetic enamel. It is recommended for suitably primed interior and exterior wood, metal and walls.

# PERFORMANCE FEATURES & BENEFITS



# SURFACE PREPARATION

- 1 Ensure the surface is clean, dry and free from all defective or poorly adhering material, dirt, grease, wax etc.
- Remove all loose or poorly adhering materials by rubbing down using suitable abrasive paper and thereafter wipe off.
- Apply a coat of suitable Primer followed by Putty (If required) to level the dents and make the surface uniform. Apply again a coat of suitable Primer. Then apply two coats of Nerolac Goody Synthetic Enamel.

## RECOMMENDED USAGE

It is recommended for all suitably primed interior and exterior wooden, masonry and metal surfaces, where high standard of durability is expected.

# RECOMMENDED SYSTEM FOR APPLICATION

## FOR MASONRY SURFACES



#### FOR METAL SURFACES



#### FOR WOODEN SURFACES



# TECHNICAL DATA



**COVERAGE\*\*** 

110 - 150 sq. ft / ltr / coat @ 30 - 40 μ m.





DRYING TIME

Surface Dry: 25 min Tack Free: 2.30 hrs



THINNING



RECOATING

Min. 8 hrs. (@27° $\pm$  2°C &RH 60  $\pm$  5%)



Upto 25% by volume using Nerolac Thinner





\*\*Actual coverage may vary depending on Method. Condition of Application. Surface Porosity & Shade.

# **PRECAUTIONS**

- 01) Stir the content well before use.
- 02) Store in a cool and well ventilated place, protected from heat and direct sunlight.
- 03) Shelf life: 12 months from the date of manufacture of original sealed containers under normal conditions.



- 04) Keep out of reach of children's.
- 05) Use under well ventilated conditions.
- 06) Avoid contact with eyes and skin. Use protective clothing such as overalls, goggles, masks and gloves during application.
- 07) Spillage on skin should be removed immediately with water, cleanser or soap.
- 09) Eyes should be properly flushed with water and medical attention sought immediately.
- 09) In the event of inhalation seek medical attention immediately.

SAFETY FEATURES: Non-Flammable.



## COLOR:

As per Goody Synthetic Enamel Shade Card.

